

HOW TO CHECK WHICH FIREPIT IGNITION YOU NEED?

BTU Output? Overhead Combustible?
Power or Battery or Manual? Side Combustible?

	BTU	Overhead Combustible Clearance	Side Combustible Clearance	Battery	Electricity
 MANUAL	60K	120" or 84" * overhead to combustibles * depends on model	36" side to combustible	No	No
 PUSH BUTTON	60K-175K	84"	36"	Yes	No
	* Only for Low Clearance Models Upgrade				
 PILOT SYSTEM	60K-250K	No overhead combustibles	36" or 48" * * depends on model	No	No
 ELECTRONIC	Low Clearance 60K-175K	84"	36"	No	120V 24V
	Other Systems 60K-250K	84"	36"	No	24V